



CRP Control

For QuikRead go Instrument and QuikRead go Plus Instrument.



Allow the control to stabilize for 30 minutes at room temperature before use.





1 Remove the foil cover from the cuvette. Do not touch the clear flat surfaces in the lower part of the cuvette.




2 Mix the control vial gently by swirling. Do not shake to prevent foaming! In case a film appears on top of the vial, wait until it bursts or carefully remove it with a corner of lint-free paper. Keep the bottleneck clean.




3 Tilt the control vial until the control solution reaches the bottleneck. Place the sample collector almost horizontally just below the control surface at the mouth of the vial. Fill the capillary part of the sample collector completely.




Note! Do not place the sample collector in the foam or inside the control vial. If there is excess sample or air bubbles on the sample collector, discard it and take a new sample. Do not wipe the sample collector.




4 Insert the sample collector into the cuvette within 2 minutes.



5 Close the cuvette tightly with the easy CRP reagent cap. Do not press down the coloured inner part of the reagent cap. Perform the test within 15 minutes.



6 Choose Quality Control on the screen of the QuikRead go instrument. Insert the cuvette into the measurement well of the instrument. The barcode should be facing you.



7 Measurement time is 2 minutes. The result is displayed on the screen, and the cuvette rises automatically when the measurement is completed. The acceptance limits of the control are in the labelling.

Storage

Opened vial is stable for 2 months at 2...8°C.

Note! Do not discard the rubber stopper.

Avoid using the last drops of the control.